







Instalation manual

ARSAL: BAR 1D1W1B1S




Element symbol	Dimensions	Code	Package
1	401	BAR_1W1D1B1S.004	1/1
2	1209	BAR_1W1D1B1S.005	1/1
3	1209	BAR_1W1D1B1S.006	2/2
4	458	BAR_1W1D1B1S.007	2/2
5	401	BAR_1W1D1B1S.010	2/2
6	765	BAR_1W1D1B1S.019	2/2
7	396	BAR_1W1D1B1S.002	1/1
8	1289	BAR_1W1D1B1S.003	1/1
9	404	BAR_1W1D1B1S.008	1/1
10	802	BAR_1W1D1B1S.009	2/2
11	794	BAR_1W1D1B1S.011	2/2
12	585	BAR_1W1D1B1S.013	2/2
13	393	BAR_1W1D1B1S.014	1/1
14	1209	BAR_1W1D1B1S.015	1/1
15	960	BAR_1W1D1B1S.016	1/1
16	802	BAR_1W1D1B1S.020	2/2
17	350	BAR_1W1D1B1S.021	2/2
18	335	BAR_1W1D1B1S.022	2/2
19	788	BAR_1W1D1B1S.001	2/2
20	353	BAR_1W1D1B1S.018	2/2
21	445	BAR_1W1D1B1S.035	2/2
22	393	BAR_1W1D1B1S.012	1/1
23	768	BAR_1W1D1B1S.W1	3/3


1x y1	1x p12	1x f28	1x n14	1x p3	8x p25	72x p3	8x d1	8x s1	8x j8	4x a143
3x n221.01	1x m1p	1x 2-m1l	1x z1	1x p52	60x L-350	60x i1	8x s2	8x s1	8x j8	4x a143
1x m1p	1x 2-m1l	1x z1	1x p52	5x p52	4x k1	4x k1	12x f11	12x f11	4x a143	2x a145
1x a145	6x b119	16x r1	16x r16	16x r16	16x r16	16x r16	16x r16	16x r16	16x r16	16x r16




1




3




2




4




ВРЕМЯ СТОЛ
 МАГАВИН МЕБЛВ




7




8




5




6




11




12



9



10






BRIS TO L
 • МАГАЗИН МЕБЛІВ •


13

14

BRISTOL
• МАГАЗИН МЕБЛІВ •



16



15

