








Instalation manual

SZAFKA RTV 140 INES 2




Element symbol	Dimensions	Code	Package
1	1379 450	RTV_2S_alyzi.001	1/2
2	1313 437	RTV_2S_alyzi.002	1/2
3	1313 437	RTV_2S_alyzi.003	1/2
4	652 220	RTV_2S_alyzi.004	2/2
5	652 220	RTV_2S_alyzi.005	2/2
6	227 415	RTV_2S_alyzi.006	1/2
7	1304 60	RTV_2S_alyzi.007	1/2
8	186 417	RTV_2S_alyzi.008	1/2
9	591 120	RTV_2S_alyzi.009	1/2
10	400 120	RTV_2S_alyzi.010	1/2
11	400 120	RTV_2S_alyzi.011	1/2
12	454 665	RTV_2S_alyzi.018	1/2
13	609 402	RTV_2S_alyzi.021	1/2
14	489 443	RTV_2S_alyzi.016	1/2
15	489 443	RTV_2S_alyzi.017	1/2


2x		φ3x16 mm	p52
2x		L-400	mm
1x		z1	
2x		n260.01.007	n260
1x		y1	
30x		φ8x30 mm	fl
40x		l1	
30x		φ3x12mm f/6	r1
10x		φ3.5x16 mm	p25
24x		φ3.5x16 mm	p25
10x		φ8x50 mm	s1
10x		φ8x50 mm	e1
2x		M4x25 mm	j8
5x		k1	
30x		r16	




1




3




2




4




5




7



6



8



10

9

! a=b

