







Installation manual

MELISA




Code	Dimensions			Package
	mm	mm	mm	
001	1950	450	16	1/3
002	1283	450	16	1/3
003	1066	446	16	3/3
004	984	433	16	1/3
005	1012	364	16	3/3
006	980	364	16	3/3
007	984	300	16	3/3
008	368	450	16	1/3
009	352	433	16	1/3
010	352	433	16	1/3
011	600	236	16	1/3
012	1468	283	16	2/3
014	948	430	16	3/3
015	1300	283	16	2/3
016	1300	283	16	2/3
017	100	1850	16	1/3
018	100	1850	16	1/3
019	451	283	16	2/3
020	434	280	16	2/3
021	434	280	16	2/3
022	433	280	16	2/3
023	368	283	16	2/3
024	334	283	16	2/3
025	334	280	16	2/3
026	100	439	16	1/3
027	100	398	16	2/3
028	100	398	16	1/3
029	1378	455	3	1/3
030	1321	355	3	1/3
031	374	975	3	1/3






 <p>m28¹</p>	 <p>m28²</p>	 <p>m27 2x</p>	
 <p>l1 120x</p>	 <p>a44 4x</p>	 <p>p17 Ø5x60 f3 Ø10x50</p> <p>1x</p>	
 <p>b119 2x</p>	 <p>a143 2x</p>	 <p>n14 1x</p>	 <p>d1 20x</p>
 <p>s2 52x</p>	 <p>s1 4x</p>	 <p>e2 Ø6,3x13 12x</p>	 <p>p21 Ø4x30 2x</p>
 <p>p25 Ø3,5x16 14x</p>	 <p>f13 Ø8x20 1x</p>	 <p>k1 8x</p>	 <p>z1 1x</p>
 <p>r1 Ø15x12 52x</p>	 <p>r16 52x</p>	 <p>f1 Ø8x30 46x</p>	 <p>e1 Ø5x50 4x</p>


1




3




2




4




7




8




5




6




9




11




10




12




15




16



13



14



! a=b

